JMA Weather Protection System™



WPS-NRA-4S or WPS-NRA-4A, 1/2" NRA Connector to Port

Materials (See cross reference chart below; all items sold separately)













WPS-NRA-4S WPS-NRA-4A

Port seal

1/2" right-angle connector

Prep tool

Compression tool

Torque wrench

Cross reference chart					
Boot	Connectors supported	Prep tool	Compression tool, frameset, and insert	Port seal	Torque wrench
WPS-NRA-4A	UXP-4RT-12	SP-1/2-LDF4D	HCG-CC HCG-FRAMESET-1/2 HCG-INSERTA	WPS-4F	TQ-78-F8
	UXP-MRA-12			WPS-MDF	TQ-78-F8
	UXP-NRA-12			WPS-NF	TW1412
WPS-NRA-4S	UXP-4RT-12S	SP-12S		WPS-4F	TQ-78-F8
	UXP-MRA-12S			WPS-MDF	TQ-78-F8
	UXP-NRA-12S			WPS-NF	TW1412

Step 1: Install boot and right-angle connector



Slide the boot onto the cable so that the connector opening is facing the end of the cable prior to prepping.



Prep the cable and then install the connector to complete installation. Use the instructions provided with the connector for this step.

Step 2: Install port seal and torque connection



Install the port seal onto the female port. See cross reference chart to use the correct port seal.



Torque the connector using the torque w rench. See cross reference chart to use the correct torque w rench.

JMA Weather Protection System™



WPS-NRA-4S or WPS-NRA-4A, 1/2" MRA Connector to Port

Step 3: Install boot to seal interface




Slide the boot over the elbow and over the port seal until the ribs are no longer visible.



Properly installed right angle boot. **NOTE**: All the ribs of the port seal are completely covered.


Port specification

WPS-4F compatible port specification



Surface to be free of flats, threads, or raised lettering w hose characters are taller than 1/8". () Indicates optional geometry.

WPS-MDF compatible port specification



WPS-NF compatible port specification

