

INSTALL INSTRUCTIONS C-ADP-110

Adaptor for C-MD-100 Series Mounts

Allows Attachment of C-UMM-101 Monitor Mount

TOOLS REQUIRED:

Open End Wrench- 7/16"

HARDWARE:

QTY	DESCRIPTION	PART #
2	1/4" x 1/2" Carriage Bolt	GSM31999
2	1/4" Flat Washers	GSM31005
2	1/4" Nut	GSM30005
2	1/4" Serrated Nut	GSM30023



Always!

- Read all instructions before installing any Havis, Inc. products.
- Use hardware provided with install kit.



View of C-MD-102 with plastic cover



Remove (unsnap) plastic cover



Insert 1/4" x 1/2" Carriage bolts into side square holes with threads sticking out. (one each side)

Note: The bolt may need to be lightly tapped with hammer to clear hex bolt head.



Attach flat washer and regular nut as shown.



Tighten nut in order to set the carriage bolt into the square hole. Remove nut and washer when bolt / stud is tight.



Carriage bolt / stud installed.
Do the same for the bolt on the other side.



Break off the tab on the plastic cover as shown.
Note: Only break off the two (2) tabs where the new bolts are located.



Re-attach plastic cover



Slide metal adaptor bracket onto the carriage bolt studs and fasten with 1/4" serrated nuts.
 Tighten nuts.



Attach washer and hardware as needed to attach monitor mount bracket.
Note: It is easier to do this prior to attaching adaptor bracket. (before previous step)



View of all parts assembled.
 Parts shown: C-MD-102, C-ADP-110, C-UMM-101 and C-KBM-100 on top of C-HDM pole.



Attach Monitor and keyboard