



**Series JL Self-Supporting Tower  
Figure 1C**

Moving from bottom to top, choose a tower height to find the corresponding base spread. Next go to the wind speed you need and move up the chart to obtain leg size, bracing size and spread for each section of the tower.

