

INSTALLATION INSTRUCTIONS

EM-A40001 & EM-A40002
Multi-Band/Broadband Low Profile Antenna
746-960 / 1710-2700 MHz

Congratulations on your selection of another quality antenna product from E/M Wave.

E/M Wave is committed to continually provide the greatest antenna VALUE for your wireless applications.

1. **Parts:** Verify all parts are included with the Antenna as shown in Figure 1.
 - a. Antenna
 - b. Lock Washer
 - c. 19mm Hex Nut



Figure 1

3. **Pre-Installation:**
 - a. The EM-A40001 / EM-A40002 antenna is designed for installation through a standard 5/8 inch clearance hole or an anti-rotation 5/8 inch Double "D" punched hole.
 - b. **IMPORTANT:** Clearance hole is punched through the mounting plane or bulkhead surface up to a maximum of ¼ inch (6.35mm) thickness.
 - c. For best electrical performance, the metallic ground plane surface diameter should be approximately 12 inches (305mm) or greater.
 - d. Verify that the surface surrounding the mounting hole is clean and smooth to provide proper seal between the silicone compression pad and mounting surface.
4. **Installation:**
 - a. Remove hex nut and lock washer from the N-jack mounting stud.
 - b. Insert N-jack mounting stud through the mounting hole from top side surface.
 - c. From the bottom side of the mounting surface, slide lock washer and thread hex nut over the N-jack mounting stud. Apply firm torque to hex nut until sealing pad is completely compressed between mounting surface and antenna base.
 - d. Attach feed cable with N-Type male connector (sold separately), and route to the radio transceiver.